

## Aquatrek2 Non Skid Plate Assembly & Installation Instructions



**NOTE:** Please read instructions before you begin your assembly. *\*It Really Helps.*

### Non-skid Tread Plate and Non-skid Platform Instructions

Photo 1



Place the Pre-Drilled non-skid Tread Plate on the tread as shown in photo 1. Use a 11/32" drill bit to make the holes in the tread as shown in photo 1.

First drop in the carriage bolt thru the top, then place the washer followed by the lock washer and then tighten with one of the nuts. **\*\*\*DO NOT OVER TIGHTEN OR YOU WILL CRACK THE PLATE, cracked plates caused from over tightening will NOT be covered under the 1 year warranty\*\*\***

When 1<sup>st</sup> nut is in place, use 2<sup>nd</sup> nut and tighten up against the first one.

--- Platform Plate installation. Using the same 11/32" drill bit, place your platform Plate centered on your system platform. The holes will need to be drilled between the cross-members so that no pipe below the platform is effected. Each platform is slightly different so we are unable to pre-drill these holes for you.

Drill the holes approximately 2" from the edge of the platform plate. The platform plate is 28" wide, your platform is 30" wide, there should be 1" along both edges. Please follow the warning sticker on underside of plate when drilling, also wipe off the plate and vacuum or sweep any dust created.

Place the hardware in the same order as the tread plates, carriage bolt, washer, lock washer, tighten 1<sup>st</sup> nut and then tighten 2<sup>nd</sup> nut.

**\*\*Please Note:** The carriage bolt should sink in to the head of the bolt as shown in photo 2

Photo 2

